

It is not necessary to orientate the rotor relative to the drive shaft in order to achieve locking. The AUTO-LOCK rotor mounting system allows rotors to be placed in any orientation.

Manual Lid Unlocking Procedure

In the event of mains non-availability or power failure, opening of the lid is prevented by the lid locking safety device. It is recommended that the user waits for the mains to be switched back on so that this safety device enables the lid to be unlocked.

Manual lid unlocking must only be done by someone informed of the possible danger and of the necessary precautions.



Rotating parts are a risk as they could come in contact with the user or be ejected. There is particularly high risk of injury if:

- The user attempts to manually stop the rotor
- Any object falls inside the centrifugation chamber while the rotor is running. ▲

Manual lid unlocking may be necessary under a very limited number of conditions, such as the urgent recovery of critical samples that could be damaged if left in the centrifuge rotor.

In this case the lid can be opened by using the special tool supplied with the centrifuge.



Always set the power switch to the OFF position before performing this manual procedure, even in the case of a mains power outage. ▲

Should the emergency occur due to power failure during centrifugation wait at least 10 minutes for the end of the rotor rotation. In spite of the absence of noise, the rotor could still be rotating when you need to open the lid manually. Upon opening, lift the lid by hand and observe the rotor (be careful in this operation): if it is still rotating, close the lid and wait.



Figure 1. Insert the unlocking tool horizontally into the hole on the right hand side of the instrument.

Figure 2. While pressing up with your finger, to press down with the unlocking tool, pull the lid lever toward you: the lid opens upwards.

The protection sticker must be replaced after it has been pierced (item N° 85241772).

