

KNOWLEDGE SHARING

Question/Issue/Symptom/Problem:

TSG205SA Red Solid Indicator Light After Downloading Data and Clearing Memory Log

Resolution/Answer:

If Red Solid Indicator Light stays lit, Perform Hard reset. Follow steps below:



1. Unplug unit from the power outlet.
2. Remove battery for 15 seconds. See pictures above for battery location.
3. Re-insert battery and plug back in.

Title:

How to Clear Red Solid Indicator Light on TSG205SA - Hard Reset Instructions

Audience:

Public

Author:

Ron Prickett
